

A PERFECT CONNECTION: PAIR AND GO!

BMP 8500 - THE TRENCH ROLLER.



BMP 8500: the trench roller.

1

STABLE CONNECTION THANKS TO RADIO.

- Trouble-free operation even under difficult job site conditions
- Clear and secure pairing of remote control to machine
- All important functions at a glance thanks to clearly visible LEDs



2

SIMPLE RADIO REMOTE EXCHANGE.

- Remote control unit easy to replace
- Pairing a replacement radio remote done in seconds
- Any remote can be used with any machine, increasing flexibility when a replacement is needed quickly

3

TELEMATICS – TRACK YOUR MACHINE'S STATUS.

- As an option, the machine is just a mouse click away
- Monitor machine position and status, including error codes

4

FOR GREATER ON-SITE SAFETY.

- BOMAG Operator Safety System (BOSS) reacts immediately
- Machine stops reliably if it comes too close to operator
- Visual signal warns operator of risk of machine tipping
- Manoeuvring out of danger zone then possible





5

YOU COULD HARDLY ASK FOR MORE CONVENIENCE.

- Battery charge status clearly visible on remote control display
- Remote control with two batteries
- Second battery can be charged while remote controls machine with the first
- Total runtime of both batteries: 35-40 hours



6

ECONOMIZER. COMPACTION CONTROL MADE EASY.

- Light strips show compaction progress
- System warns against over-compaction and grain breakage while identifying soft spots in the soil
- Reduces number of passes by up to 25%

7

BETTER PROTECTION FOR LONGER SERVICE LIFE.

- Enclosed exciter housing prevents water and dirt from entering
- Rugged, well-thought-out design for tough everyday construction site operation
- Intelligent layout of hydraulic hoses - minimises repairs and keeps service costs low

8

QUICKLY WIDENED FOR ALL TASKS.

- Effortlessly widen or reduce working width from 610 mm to 850 mm
- Smooth drum optionally available

Head Office / Hauptsitz:

BOMAG

Hellerwald
56154 Boppard
GERMANY
Tel. +49 6742 100-0
info@bomag.com

**BOMAG Maschinen-
handels-gesellschaft m.b.H.**

Klausenweg 654
2534 Alland
AUSTRIA
Tel. +43 2258 20202
austria@bomag.com

BOMAG (CANADA), INC.

2233 Argentinia Road, East Tower
Suites 302
Mississauga, ON, Canada
L5N 2X7
Tel. +1 800 782 6624
canada@bomag.com

BOMAG (CHINA)

Compaction Machinery Co. Ltd.
No. 2808 West Huancheng Road
Shanghai Comprehensive
Industrial Zone (Fengxian)
Shanghai 201401
CHINA
Tel. +86 21 33655566
china@bomag.com

BOMA Equipment

Hong Kong LTD

Room 1003, 10/F Cham Centre
700, Castle Peak Road
Kowloon
HONG KONG
Tel. +852 2721 6363
bomahk@bomag.com

BOMAG France S.A.S.

2, avenue du Général de Gaulle
91170 Viry-Châtillon
FRANCE
Tel. +33 1 69578600
france@bomag.com

BOMAG (GREAT BRITAIN), LTD.

Sheldon Way
Larkfield, Aylesford
Kent ME20 6SE
GREAT BRITAIN
Tel. +44 1622 716611
gb@bomag.com

BOMAG Italia

Via Roma 50
48011 Alfonsine
ITALY
Tel. +39 0544 864235
italy@bomag.com

FAYAT BOMAG Polska Sp. z o.o.

Ul. Szyszkowa 52
02-285 Warszawa
POLAND
Tel. +48 22 482 04 00
poland@bomag.com

FAYAT BOMAG RUS OOO

141400, RF, Moscow region
Khimki, Klayazma block, h. 1-g
RUSSIA
Tel. +7 (495) 287 92 90
russia@bomag.com

BOMAG APAC PTE LTD

300 Beach Road
The Concourse, #18-06
Singapore 199555
SINGAPORE
Tel. +65 6 294 1277
singapore@bomag.com

BOMAG Americas, Inc.

125 Blue Granite Parkway
Ridgeway SC 29130
U.S.A.
Tel. +1 803 3370700
usa@bomag.com

